

12160-06 Sensing Head with Water Filter

12160-35 Water Filter, Only



You can avoid failure of your 12160-06 Sensing Head, due to dirt or rust from house water lines, by installing the 12160-35 water filter. Dirt and rust can cause a malfunction of the unit's internal plunger and prevent shut-off when needed.

The in-line water filter has a $\frac{3}{8}$ " O.D. hose connection on inlet and outlet for easy installation before sensing head. (Note: Filter is labelled "IN" and "OUT" for proper flow direction.)

The reusable filter cartridge is completely visible and can be removed for cleaning by unscrewing one end. The unit is supplied with a spare cartridge.



ACE GLASS INCORPORATED

P.O. Box 688 • Vineland, NJ 08362-0688 • 856-692-3333 • Fax: 856-692-8919

TOLL-FREE: 1-800-223-4524 • FAX: 1-800-543-6752

www.aceglass.com email: sales@aceglass.com